

# Jules & Fils Classic 40mm Manual

## Setting time & date:

Running position (1)


No adjustment possible

Date adjustment position (2)

Set date: turn down

Time adjustment position (3)

Always turn clockwise!



## Water resistance

The watch:

In the course of time and due to wear and tear, the water resistance of the watch may become reduced.

Crown: always make sure that the crown is pushed fully into the case. After changing the date or the hour, put enough pressure on the crown to bring it back in position. Besides the fact that this will prevent water entering the watch, it will also reduce the amount of dust that can enter. Never pull out the crown when the watch is submerged in any liquid!

Exposure to salt water: salt is an aggressive substance and can harm your watch. The watches are made of full stainless steel but even then, we recommend cleaning the watch with fresh water and drying it with a soft dry cloth after contact with salt water.

The Strap

Our straps are made from genuine leather and are not water resistant. They can stand an accidental splash of water but we do not recommend submerging the strap consequently in any liquid. If this accidentally happens, let the strap dry in a normal atmosphere (room temperature). Don't put it on a heater or in the sun.

## Warranty

Your new Jules & Fils timepiece has been carefully inspected before packing and is covered by a two year guarantee, beginning on the date of purchase, against manufacturing and mechanical defects. The warranty excludes straps, batteries, glass, accidental damage or wear and tear.

If you need more help, please feel free to contact us by sending your question to [support@julesfils.com](mailto:support@julesfils.com). We will respond within 24h!